



Wireless Remote setup.

Open the back of the remote and insert the battery.

Remove the small flat wireless receiver from inside the battery compartment and plug it into a USB port on your laptop. Make sure the remote is turned "on". If the blue light is blinking on the receiver push the "connect" button to sync the remote and the receiver, the light should go solid blue.

Open Flip-Q software on your computer.

go to the file menu in Flip-Q.

click on action assignments.

click on the "change" button next to the action you want to assign

click in the empty field and press or click on your remote device to assign an action

repeat this for each action you want to assign

set action assignment to:

stop/start B

increase speed page up (on Mac fn key and up arrow)

decrease speed page down (on Mac fn key and down arrow)

enter/leave escape

narrow button is

**Left arrow button
Increases speed**

**Bottom narrow
Button
enter/escape
prompt mode**



**stop/start
top**

**Right arrow button
decreases speed**